


DIESEL PARTICULATE FILTER (DPF) SYSTEM

<Vehicles with closed type DPF>

Through the input signal sent from each sensor, the engine-ECU anticipates the amount of particulate matter (PM) accumulated in the DPF. Taking control of automatically regenerating the DPF under the certain condition, the engine-ECU removes the PM when the PM accumulates more than the standard. At the DPF regeneration, the DPF temperature is higher and the high temperature exhaust gas discharges.


CONTROL OVER ANTICIPATING AMOUNT OF ACCUMULATED PM

<M/T>



AK800965 AB


<A/T>



AK800966 AB

Calculating the input signal sent from each sensor, the engine-ECU anticipates the amount of PM accumulated in the DPF. The anticipation method is as follows:

Anticipation by odometer	Calculating travel distance through vehicle speed sensor, engine-ECU anticipates that PM accumulates more than criteria when specified travel distance is accumulated from previous DPF regeneration.
Anticipation by difference in pressure	Detecting difference in pressure before and after DPF through exhaust differential pressure sensor, engine-ECU anticipates amount of accumulated PM, adding compensation through exhaust differential pressure sensor ambient air temperature sensor.
Anticipation by quantity survey	Engine-ECU anticipates amount of exhaust PM based on operation conditions, which multiplying allows engine-ECU to anticipate amount of accumulated PM.




Detecting that the PM accumulates more than standard in the DPF, the engine-ECU sends the request signal to the combination meter in order to light the DPF lamp through the CAN. This allows the driver to be encouraged to drive with operating conditions effective to the automatic regeneration. When the vehicle continuously runs with the DPF lamp lighted and without the DPF regeneration, the engine warning lamp is lighted and the DPF lamp starts to blink. This shows that the amount of accumulated PM exceeds the specified amount. When the DPF automatic regeneration is performed under this condition, the DPF temperature is extremely higher depending on the operation and the DPF might be damaged. This causes the DPF automatic regeneration not to be performed when the DPF lamp blinks. Therefore, the DPF regeneration needs to be forcibly performed.

The engine-ECU assumes the increase and decrease in the engine oil level, based on the driving conditions. When the assumed engine oil level increase more than specified value, the DPF lamp blinks. This allows the driver to be informed that the engine oil level is abnormal.


DPF REGENERATION CONTROL

<M/T>



AK800967 AB

<A/T>



AK800968 AB

The DPF regeneration has the forcible regeneration by M.U.T.-III and the automatic regeneration automatically performed while the vehicle is running. The automatic regeneration is performed under the following conditions:

- Engine: after warm-up
- Transmission: D range
- Vehicle speed: 40 km/h or more
- Amount of accumulated PM exceeds specified value.

Performing the optimum engine control for the DPF regeneration, the engine-ECU increases the temperature up to the point at which the DPF regeneration can be carried out, and then keeps the temperature to burn the PM.

1. RISING TEMPERATURE CONTROL

Performing rising temperature control having two steps, the engine-ECU increases the temperature up to the point at which the DPF regeneration can be carried out. At the first, the engine-ECU drives the variable geometry control solenoid valve and the throttle valve control servo and then performs the fuel injection with the optimum injection pattern, decreasing the intake air amount. This allows the high temperature exhaust gas to discharge as well as allows the catalyst in the front of the DPF to be heated to about 200°C, resulting in the catalyst activated, which is monitored by the No. 1 exhaust gas temperature sensor.

After the catalyst is activated, the engine-ECU performs the fuel injection called "post-injection" having more retarded timing than the usual timing. This allows the oxygen to react, in the catalyst, with the HC contained in the exhaust gas as


well as allows the exhaust gas temperature to reach about 600°C at which the DPF regeneration can be carried out, which is monitored by the No. 2 exhaust gas temperature sensor (catalyst temperature).

2. REGENERATION CONTROL



When starting to perform the DPF regeneration, the engine-ECU carries out the feedback control so that the temperature in the DPF can stabilize at about 600°C through the output signal of the No.3 exhaust gas temperature sensor (DPF temperature). Controlling the injection amount of the post-injection and the intake air amount regulates the temperature in the DPF.

When being out of the regeneration condition during the automatic regeneration, the DPF regeneration stops. If, however, satisfying the regeneration condition right after that, the DPF regeneration is continuously carried out.

No. 1 EXHAUST GAS TEMPERATURE SENSOR, No. 2 EXHAUST GAS TEMPERATURE SENSOR (CATALYST TEMPERATURE), No. 3 EXHAUST GAS TEMPERATURE SENSOR (DPF TEMPERATURE)




The No. 1 exhaust gas temperature sensor is installed to the center of the catalyst, the No. 2 exhaust gas temperature sensor (catalyst temperature) is installed to the downstream area of the catalyst and the No. 3 exhaust gas temperature sensor (DPF temperature) is installed to the downstream area of the DPF. Each sensor detects the temperature in the each area through the change in the thermistor resistance and outputs the voltage to the engine-ECU in accordance with the temperature. The engine-ECU performs the DPF regeneration control through this output voltage. The sensor characteristics are as shown in the charts.





AK901057 AB

EXHAUST DIFFERENTIAL PRESSURE SENSOR




AK702129AB

The exhaust differential pressure sensor is installed around the upper area of the DPF. Using the piezo resistive semiconductor, the exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area. The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage. The sensor characteristics are as shown in the charts.



AK702130AB

EXHAUST DIFFERENTIAL PRESSURE SENSOR AMBIENT AIR TEMPERATURE SENSOR



The exhaust differential pressure sensor ambient air temperature sensor is around the upper area of the DPF. The exhaust differential pressure sensor ambient air temperature sensor detects the exhaust differential pressure sensor ambient air temperature through the change in the thermistor resistance and outputs the voltage to the engine-ECU in accordance with the exhaust differential pressure sensor ambient air temperature. The engine-ECU uses this output voltage for the compensation in calculating the amount of accumulated PM through the exhaust differential pressure. The sensor characteristics are as shown in the charts.

