



FOR ALL ISUZU MODULES, FOR THE DPD (DPF) REMOVAL TO BE SUCCESSFUL PLEASE USE A HIGH END AUTOMOTIVE SCAN TOOL LIKE GSCAN TO COMPLETE A "DPD STATUS RESET".

THIS FUNCTION IS FOUND UNDER "SPECIAL FUNCTIONS" OF THE DIAGNOSTIC SCAN TOOL.

SEE EXAMPLE BELOW

